



Pack	Cat No.	Description
5	SQ777X	10A double powerpoint with extra switch
5	SQ777XS	10A double powerpoint with extra switch & safety shutters



Pack	Cat No.	Description
5	788PXP	10A 2 pole single powerpoint with extra 2 pole switch, caravan type
5	788PX	10A 2 pole single powerpoint with extra switch



Pack	Cat No.	Description
10	1/788	10A single pole single powerpoint
10	1/788P	10A double pole single powerpoint, caravan type
10	1/788P15	15A double pole single powerpoint, caravan type



Pack	Cat No.	Description
5	2/788P	10A double pole double powerpoint, caravan type
5	2/788	10A single pole double powerpoint
5	2/788P15	15A double pole double powerpoint, caravan type
5	2/788PNS	10A double pole double powerpoint with neons & safety shutters, caravan type



Pack	Cat No.	Description
2	777EL30	30mA Electresafe powerpoint 10A
2	777EL30/1015	30mA Electresafe powerpoint with 10A & 15A outlets
2	777EL30G	30mA Electresafe powerpoint for use on generators, 10A
2	777EL30G1015	30mA Electresafe powerpoint for use on generators, 10A & 15A outlets